



Part Number 154141C

PowerFlow Kit KTM Freeride 350

(incl. pre-oiled air filter (FR), wire filter cage, wire fitment cage and intake)



Instructions:

Step 1:

Remove the OEM airbox and filter out of the bike (picture 1).

Picture 1





Step 2:

Assemble the filter cage into the air filter. Put the fitment cage on top of the air filter and secure the cages with the rubber grommet (picture 2, 3 and 4).

Picture 2



Picture 3



Picture 4



Step 3:

Mount the Twin Air intake into the engine inlet system (picture 5 and 6)

Picture 5



Picture 6





Step 4:

Mount the filter on the intake and apply downward pressure. The fitment cage will make sure the filter stays in the right place. The seat will then secure the complete filter system.

Picture 5



Picture 6



If you have any other questions feel free to contact us. For contact information go to www.twinair.com or www.twinairusa.com.

Twin Air Parts and Accessories

- PowerFlow Replacement Air Filter: #154141FR
- Replacement Oil Filter: #140019

Twin Air Cleaning and Oiling Products

- Bio Dirt Remover: #159004
- Liquid Bio Power: #159017
- Bio Pack (Dirt Remover / Liquid Power): #159020
- Bio Spray: #159018M
- Twin Air Bio System: #159000BIO

For more details or to purchase these or other Twin Air products go to www.twinair.com, www.twinairusa.com or visit your local Twin Air Authorized Dealer.