



**TPS connection tables:**

Connect the TPS-tool pins to the TPS-sensor pins as shown in below tables.

Extra information:

- When turning on the TPS-tool unconnected, 1 . will appear on the display.
- Measurement range 0-20k ohm.

Yamaha YZF 450 2010-2013	
TPS-sensor:	TPS-tool pins:
Black	Black
Yellow	Red


Kawasaki KXF 250 2011-2012 KTM SXF 250 2011-2012 SXF 350 2011-2012 KTM EXC 250/350/450/500 2012-2015	
TPS-sensor:	TPS-tool pins:
Top	Black
Middle	Red

Kawasaki KXF 250 2013-2015 450 2009-2015 KTM SXF 250 / 350 / 450 2013-2015 Suzuki RMZ 250 2009-2015 RMZ 450 2008-2015	
TPS-sensor:	TPS-tool pins:
Black	Black
Yellow	Red

Honda CRF 250 2013-2015 CRF 450 2011-2015 Yamaha YZF 250/450 2014/2015	
TPS-sensor:	TPS-tool pins:
Bottom	Black
Middle	Red



Picture 13



Picture 14